


Ersatzhaube / Replacement dome

VisionStar M pro



MPK Metall- und
Plastikverarbeitung GmbH & Co. KG
Friedrich-Ebert-Str. 298-300
D-58566 Kierspe
mpk-kierspe.de



DE Montagehinweise

1. Öffnen Sie die Dachhaube.
2. Entfernen Sie die vier Kunststoff-Splinte, die Glashaube und Oberrahmen miteinander verbinden.
3. Entfernen Sie die alte Haube und setzen Sie die Ersatzhaube in den Rahmen ein.
4. Setzen Sie die mitgelieferten Kunststoff-Splinte wieder ein.

Achten Sie beim Wiedereinsetzen darauf, dass die Kunststoffsplinte einrasten. Ausstellersplinte werden mit der flachen Seite nach oben eingesetzt.

Dauerlüftung

Die Ersatzhaube wird von Werk aus ohne Dauerlüftung ausgeliefert. Durch Kürzen der eingesteckten Dichtung, kann die Dachhaube bei Bedarf umgerüstet werden.

Das mitgelieferte selbstklebende Dichtungsgummi wird dann zusätzlich eingesetzt.

Dichtung gekürzt auf 90 cm
Scharnierseite, äußerer Kanal

Selbstklebende Dichtung
Hinten, innerer Kanal

Dichtung gekürzt auf 34 cm
Scharnierseite, äußerer Kanal

Selbstklebende Dichtung
Hinten, innerer Kanal

Pflegehinweise

Verwenden Sie zum Reinigen der Haube ausschließlich klares Wasser und einen weichen Schwamm



Scharfe Reinigungsmittel können den Kunststoff angreifen und brüchig machen.

EN Fitting instructions

1. Raise the dome.
2. Remove the four plastic splint pins that connect the glass and upper frame.
3. Remove the dome and insert the new dome.
4. Put the plastic splint pins back in place.

Pay attention that the pins positively click into the lockes position when reinstalling the dome. The lever arm pins should be re-installed with the flat side towards the dome.

Permanent ventilation

The Replacement dome is supplied without permanent ventilation. A rubber seal is fitted around the outer seal channel closing the ventilation. If required, the rooflight can be converted to a permanently ventilation.

The self-sealing rubber is then additionally required.

Seal shortened to 90 cm
Hinge side, outer channel

Self-adhesive seal
Rear, inner channel

Seal shorted to 34 cm
Hinge side, outer channel

Self-adhesive seal
Rear, inner channel


Care Instructions

The rooflight should only be washed by hand, using a sponge with plenty of clean water to avoid scratching.



Causic detergents and solvents may attac the plastic and make it brittle or disintegrate.

ohne
Dauerlüftung /
Without
free-air-flow



Dauerlüftung
75cm² /
With free-air-flow
75cm²



Dauerlüftung
150cm² /
With free-air-flow
150cm²



mpk-kierspe.de/Downloads